



## **Smartwatch**

### **Maxcom FW42 Gold / Silver**

#### **User Manual**

Please refer to this manual before using the product

V1.0

**Notes:**


1.1 The company reserves the right to modify the contents of this manual without any further notification. It is normal that some functions may vary in certain versions of software.

1.2 Please charge this product with the configured cable for no less than 2 hours before using it.

1.3 Before using the product, you need to connect the APP synchronization time and set your personal information.

1.4 This product supports IP68 rank waterproof, not suitable for deep sea diving. Hot water, tea and other corrosive liquids are destructive to the watch, and will not be able to enjoy the product warranty and free maintenance services.

## 1. Product Overview



### Models can be paired with:

Android phones: support 5.1 and above

Iphones: support iOS 9.0 and above





### Glory Fit App:

1. Please scan the QR code below to download APP or find it in App Store (iOS) or Google Play (Android).



## 2. Buckle adjustment method (For Buckle Metal Straps)

1. Buckle diagram (Figure 1).
2. First use the stylus to lift the buckle and move the buckle to your proper position (Figure 2).
3. The position of the buckle seat is aligned with the groove on the opposite side of the strap (Figure 3).
4. Hook on the thin bar, then push down the buckle(Figure 4).



### 3. Main Functions

#### 3.1 Basic Operating

##### **Turn on the smart bracelet**

Press and hold the side button for 3 seconds to turn it on; short press the side button to wake up the bracelet in standby mode.

##### **Turn off the smart bracelet**

Long press the side button for 3 seconds to turn it off.

#### 3.2 Dial Selection

Long press the dial to enter into selection page, slide right/left to view all, then click to choose the one to be used.

- 1.Slide up to Main menu
- 2.Slide down to Status bar
- 3.Slide right to Message
- 4.Slide left to Shortcut menu

### **3.3 Pedometer, Calories, and Distance**

Click Pedometer icon to see all the historical data. Swipe right to return to previous menu, or short press the side button to return to the main interface directly.

### **3.4 Heart rate**

Click the heart rate icon to start monitor which would take about 1min. Slide right to exit or press the side button return to the main interface directly. The bracelet should be worn tightly on the wrist during the monitor.

### **3.5 Blood Pressure**

Click the blood pressure icon to start monitor which would take about 1min. Slide right to exit or press the side button return to the main interface directly. The bracelet should be worn tightly on the wrist during the monitor.

### **3.6 Blood Oxygen**

Click the blood oxygen icon to start monitor which would take about 1min. Slide right to exit or press the side button return to the main interface directly. The bracelet should be worn tightly on the wrist during the monitor.

### **3.7 Sleep Monitor**

Click the sleep monitor icon to enter, the watch will display sleep data of the previous day. Slide right to exit or press the side button return to the main interface directly. Sleep history record can be checked on the APP.

The default sleep monitoring time for the bracelet is from 18:00 p.m. to 10:00 a.m. If you wear the smart bracelet to sleep, then you can check the sleep time of last night at 8:00 in the morning at the sleep interface. When the bracelet is successfully paired with APP, the sleep data will be automatically synchronized in real time (or manually refreshed) to upload the data of the bracelet to the APP.



Menu interface



Heart rate



Blood pressure



Blood oxygen



Sleep

### 3.8 Sport modes

(1) Sport Modes: Walking, Walking indoor, Running, Running indoor, Cycling and Climbing

(2) Sport records saved on the bracelet can be check on APP.



Walking



Indoor walking



Cycling



Run



Indoor running



Climbing

### **3.9 Message**

Click the message icon to enter and check messages pushed from the paired phone. The bracelet can save up to 3 messages. Slide right to exit or press the side button return to the main interface directly.

### **3.10 Download QR Code**

Scan the QR code to download the APP through application market or browser. Slide right to exit or press the side button return to the main interface directly.

### **3.11 Music**

The bracelet can remote control the music play of the paired phone. Slide right to exit or press the side button return to the main interface directly.

### **3.12 Find Phone**

Click find phone icon to enter, and one click to start to find connected mobile phone. Phone will give out rings to be found.

### **3.13 Stopwatch**

Click the stopwatch icon to enter into stopwatch page, click the start icon to start, and click the left icon to save. Stopwatch records can be saved up to 4. click the right icon to pause, if click the reset icon now, the current record would be cleaned. Slide right to exit or press the side button return to the main interface directly.

### **3.14 Setting**


Click the setting icon to enter into setting page, which includes brightness adjustment, APP download QR code, about, reset, and shutdown. Slide right to exit or press the side button return to the main interface directly. Brightness Adjustment: click “⊕” to increase, and click “⊖” to decrease.

(1)APP download QR code: Use browser/APP store/Google play to scan and download.

(2>About: Click to check Name, Bluetooth and version number.

(3)Reset: Click into reset page, click “√” to reset the bracelet, click “×” to exit.

(4)Shut Down: Click into power off page, click“√”to turn off the bracelet, click “×” to exit.



### 3.15 Slide down the dial interface to enter into Status Bar

The Status Bar includes: Setting, do not disturb mode, brightness adjustment, date, battery, and connection status.

### 3.16 Slide left to enter into shortcut menu

Short cut menu includes: Pedometer, heart rate, sleep monitor, and Female functions.

### 3.17 Female Functions

Registered APP users with setting of female gender can set their physiological cycle. Only After APP setting done, the female function icon would only appear in the bracelet.

## 4 APP download and connection


### 4.1 APP download and installation

(1) Use your mobile phone to scan the QR code in the bracelet to download the app (or search and download from Play Store/ App Store Glory Fit APP) and follow the prompts to install it.

### APP and bracelet connection

Click to enter the APP, select "Login" or "Registered", or "Login without registering" (Figure 8), successful login--tap the watch icon at bottom to enter into Equipment page (Figure 9). Tap "Bind New Device" and Enter into Device Selection page (Figure 10). Tap on the photo of KW10PRO and enter into Connection Page (Figure 11), then find the right Bluetooth name of your device and tap it (Figure 12).





## 5. Other functions (can be used after connecting APP)

### 5.1 Notification Reminder

Tap "Notification Reminder" to enter into setting page. For each App, to select yes, tap it to blue color; to select no, tap it to gray color. When the phone gets new messages from selected Apps or incoming calls, they can be pushed to the bracelet and you can see all notifications on the smart bracelet. Unread messages can be checked in "Message View" interface. The bracelet can display up to 3 unread messages and will only show the latest one.

## **5.2 Reminder Settings**

Includes Sedentary reminder, drinking water reminder, alarm reminder (up to 5), medicine reminder and meeting reminder.

## **5.3 Do not disturb mode (DND mode)**

Click to enter "Do not disturb mode" interface, Switch on the key and click save to start the mode. Notification will not be received during 22:00- 08:00.

## **5.4 Lift the wrist for bright screen**

Go to "Device" interface on APP - Switch on "Lift the wrist for bright screen" key, You can brighten the screen by lifting wrist when screen is off.

## **5.5 Continuous heart rate monitoring & Continuous Blood Oxygen Monitor**

Click to "Device" interface on app- Turn on the "Heart Rate monitoring" key or "Blood Pressure Monitor". When the watch worn on wrist, It monitors once every 5 minutes by default. And heart rate will be automatically detected once it reaches the set interval duration.

## **5.6 Sync Google Fit**

Switch to blue to turn on this feature.

## **5.7 Find the Device**

Click it on the APP to find your device, and the smart watch will vibrate when connected.

## **5.8 Camera Control**

Click to "Device" interface on app, and tap "Remote Photography", the camera icon will show up on your watch, shake the bracelet and the phone will take a photo in 3 seconds, then the photo will be saved in the gallery. Since Android systems update resources in different ways, you might need to check the pictures in your phone file management.

Note: For the permission request that pops up automatically, please click Allow.

## **5.9 More settings**

Set unit, clock format, and check Bluetooth address, reset the watch, and do firmware update here.

## **5.10 Enable background running permission**

Follow the guide on app to make sure the app can run automatically in your phone.

### 5.11 Unbound

Tap to unpair the bracelet from the paired mobile phone

## 6. Solutions of Troubles

In case there's a problem during the using of the smart bracelet, please solve it accordingly by the following ways. If the problem still exists, please contact the seller or designated maintenance personnel.

### 6.1 The bracelet cannot be turned on

1. Press the display touch area for over 3 seconds
2. Make sure there is enough battery, please recharge the bracelet and start it again.
3. If the bracelet is left for a long time and the normal charger does not respond, please try charging with an output power of 5V/2V.

### 6.2 The bracelet shuts down automatically

It is possible that the battery is used up. Please recharge the bracelet and start it again.

### 6.3 Short battery performance

Make sure the battery has been completely charged. (At least two hours)

### 6.4 Bracelet cannot be charged

1. Check if the battery can be used. The performance of battery may be reduced after several years.
2. Check if the charger is working properly, (both the adapter and cable), if not, try another one.
3. Check the connection of watch and cable during charging.



Find your user manual language



## **GUARANTEE**

- The manufacturer guarantees that the Maxcom Smartwatch product is free from material defects and implementing measures for normal use within 24 months from the date of purchase.

In the event of a defect or malfunction, please contact retailer or authorized distributor. The proof of purchase needs to be attached to the submitted complaint. The guarantor will repair or replace free of charge products that do not meet the parameters specified in the Warranty within a reasonable time.

- This Warranty applies to the original purchaser only. Its range covers the territory of the EU
- The warranty does not exclude, limit or suspend the buyer's rights resulting from the provisions on the warranty for defects in the sold item
- Technical and warranty support is available at [www.maxcom.pl](http://www.maxcom.pl)

## **THE WARRANTY DOES NOT COVER:**

- Normal wear and tear, including batteries (rechargeable batteries) unless the damage was caused by defects in materials or workmanship
- Mechanical, thermal, chemical and other damages
- Defects resulting from: improper use and not obeying instruction manual; making unauthorized changes; use or storage in an inconsistent manner with the technical specifications of the product; improper maintenance; application items other than the one supplied or the use of any items not intended for use with the product; technical work performed by unauthorized personnel.

The above applies to the rules for the validity of the warranty on the goods consumption resulting from Directive 1999/44 / EC.

## **SIMPLIFIED DECLARATION OF CONFORMITY**

This equipment complies with the Directive of the European Parliament and of the Council 2014/53 / EU on radio equipment and telecommunications and their mutual recognition. This equipment can be used in all EU countries European Union and in all countries where the Directive applies 2014/53 / UE.

## **NOTE: THIS EQUIPMENT SHOULD NOT BE DISPOSED WITH WASTE COMMUNAL!**

The product should be used by selective collection in prepared for this points. Proper handling of used electrical and electronic equipment contributes to the avoidance of harmful consequences for human health and the environment resulting from the presence of dangerous elements, as well as improper storage and processing of such equipment. The device contains a Li-ion battery. Used batteries are harmful to your health the environment. They should be stored in a specially designated point, in a suitable container in accordance with applicable regulations. Batteries and accumulators must not be disposed of with municipal waste, they must be handed over to collection points.

## **CAUTION: DO NOT PUT BATTERIES IN A FIRE**

Manufacturer and Distributor:

Maxcom S.A.

Ul. Towarowa 23a

43-100 Tychy

Poland